

▶ Standard color scale ◀



3.0



4.0



4.5



5.0



5.5



6.0



6.5



7.0



7.5



8.0



8.5



9.0



**pH Test Kit**



Read instructions before use

**ASINMEDIC CO., LTD.**

Tel. 6689-185-8999, 6690-898-5188

[sales@asianmedic.com](mailto:sales@asianmedic.com)

[www.asianmedic.com](http://www.asianmedic.com)

### ► Package contents

- |                      |          |
|----------------------|----------|
| 1) Reaction bottle   | 1 set    |
| 2) Syringe 3 ml.     | 1 piece  |
| 3) Indicator Reagent | 1 bottle |

### ► Cautions

- 1) Immediate close all reagent containers after use.
- 2) Always wash your hands after using the kit.
- 3) Keep the kit out of direct sunlight and away from heat, food, pets, and the reach of children.

### ► Testing procedure ◀

#### Step 1 :

Add 1.5 ml. of water sample into the reaction bottle with syringe 3 ml. contained syringe.



#### Step 2 :

Add 1 drop of indicator reagent and swirl gently to mix the solution



#### Step 3 :

Compare the color of the solution with standard color scale by placing the uncapped reaction bottle at the center of color ring to match the color of the solution and the ring.

